



OWNER'S GUIDE



D65-1000 SUPER CHAINSAW



SPECIFICATIONS

TYPE:	Clinton one cylinder, two-cycle, air-cooled.	BEARINGS:	3 Needle Bearings — 1 Ball Bearing
BORE & STROKE:	2 1/4" Dia. x 1 1/2" Stroke.	CHAIN OILING:	Push-Button type for operator control to suit various cutting conditions.
DISPLACEMENT:	5.76 Cubic Inch.	MUFFLER:	Industry approved stainless steel spark arrester. Exhaust gases and heat are directed away from operator.
HORSEPOWER:	6 HP (Industry Rated).	HANDLES:	Chrome plated steel tubular handle. Hand-sized for easy grip — permits flush cutting.
ENGINE WEIGHT:	22 1/4 lbs.	ROLLER TIP GUIDE BARS:	Patented — cuts as much as 20% faster... reduces chain to guide bar friction... extends life of guide bar, chain and sprocket.
FUEL:	Oil and gasoline mix — 1/4 pint to one gallon for first 5 hours — 1/2 pint per gallon thereafter.	GUIDE BAR LENGTHS:	14", 16", 20", 26", and 30" STELLITE-TIPPED induction hardened guide bars and 16", 20", 26", and 30" ball bearing ROLLER TIP. Also available with 15" non-pin, plunge-type bowsaw attachment.
FUEL TANK:	1 1/2 quart capacity.	CHAIN:	1/2" pitch, .058 gauge standard equipment. 1/2" pitch, .063 gauge used on bowsaws.
CARBURETOR:	Diaphragm with built-in fuel pump for all position cutting.		
POWERHEAD ASSEMBLY:	Consists of high quality precision die-cast aluminum cylinder block with integral cast-iron liner plus sectional die-cast magnesium strut and handles for low cost replacement if damaged.		

CLINTON ENGINES CORPORATION

CHAINSAW-OUTBOARD DIVISION

CLINTON, MICHIGAN

OPERATION OF THE TWO CYCLE ENGINE


In a two cycle engine, intake, compression, power and exhaust are completed in two strokes of the piston. A power stroke results with every revolution of the crankshaft. On the upward stroke of the piston, a partial vacuum is created in the crankcase. (See Figure No. 1)

First, the vacuum and outside air pressure cause the reed valve between the crankcase and the carburetor to open. The air-fuel mixture from the carburetor flows in to the engine crankcase. Then, the downward movement of the piston causes the reed valve to close while continued downward movement of the piston compresses the fuel charge in the crankcase. Near the bottom of its stroke the piston uncovers the intake by-pass port, which connects the combustion chamber and the crankcase.


As the piston moves upward on its stroke, it passes the intake port, closing the port opening. Its continued upward movement causes the fuel mixture in the cylinder to be compressed. At the same time a new fuel charge is drawn into the crankcase. As the piston nears the top of the compression stroke, the fuel mixture in the combustion chamber is ignited by the spark. The explosion and expansion of gases forces the piston down on its power stroke. Power is not delivered for the full length of the stroke. Some time is required to rid the cylinder of burned gases, so that it may receive a fresh fuel charge from the crankcase.

As the piston nears the bottom of its stroke, it uncovers the exhaust port opening slightly ahead of the intake port. This permits taking advantage of the pressure of the exhaust gases in the cylinder, which are still comparatively high, and allows them to start escaping. Further downward travel of the piston uncovers the intake by-pass port. The incoming charge assists in forcing the exhaust gases out of the cylinder, to complete the cycle.


The chief attributes of the two cycle engine are its lightweight, low cost and powerful but simple operation. With only three basic moving parts (crankshaft, piston and rod), maintenance costs are at a minimum while efficiency is at a maximum.



COMPRESSION



POWER



EXHAUST

Figure No. 1

ASSEMBLY OF GUIDE BAR AND CHAIN




Figure No. 2

1. Slide the guide bar over the mounting studs to the full length of the guide bar slot. (See Figure No. 2)
2. Place the chain around the guide bar so that cutting edges of teeth on top of the guide bar point away from the engine unit.
3. Place the Chain over clutch drum onto the drive sprocket, then place drive links into bar groove.
4. Pull the guide bar out from the engine unit until the chain slack is taken up. Make sure that the chain drive links at the bottom of the bar are properly seated in the bar groove.
5. Place the tension plate on mounting studs with the flat pad against the guide bar
6. Make sure that the chain tension lug, located in the chain tension plate, fits into the slotted holes.
7. Put washers and nuts on the guide bar mounting studs to make them snug, but not tight, against the guide bar mounting plate.
8. While holding with upward pressure at end of guide bar, turn tension adjusting screw clockwise until the chain has a free sag of $\frac{1}{8}$ inch from the bottom of the guide bar on stellite tip bars. On roller nose bars the chain should be snug. If the blade is not in the up position as high as it will go against the guide bar studs, it will cause excessive wear on the top of the guide bar closest to the sprocket.
9. Securely tighten the mounting stud nuts and then re-check for proper chain tension. If the tension has changed, then loosen the mounting stud nuts and repeat the procedure outlined in step 8.
10. Be sure the chain is properly tensioned at all times. Check it often. A chain that is too tight will interfere with proper cutting and will cause serious damage to the guide bar and the engine. CAUTION: Check and maintain chain tension for long life and best operation. Use extra care with a new chain until the stretch, which is most noticeable in the first hour of cutting, is eliminated.

CAUTION — Never Adjust Chain Tension While Engine Is Running.

FUEL PREPARATION AND LUBRICATION

Correct fuel mixture is one of the most important points in operating your engine. Follow these instructions carefully, and **DO NOT POUR UNMIXED GASOLINE OR OIL INTO THE FUEL TANK.**

Type of Oil

Use SAE #30 motor oil outboard. A detergent oil or oil containing additives is not advised.

Type of Gasoline

A good grade of regular gasoline, available at your local filling station, is recommended for use in your chain saw engine. High octane or premium fuels offer no advantages and **ARE NOT** advised.

Mixing Ratio of Oil to Gasoline

Thoroughly mix $\frac{3}{4}$ pint of oil with each gallon of gasoline. This rich oil mixture may cause difficulty

with idling, but it is necessary to properly wear in the various parts of the engine. After 5 hours break-in ratio may be changed to not less than $\frac{1}{2}$ pint to 1 gallon of regular gasoline.

Chain and Guide Bar Lubrication

A positive action oil pump located in the lower portion of the fuel tank (See Figure No. 3) provides ample lubrication to the cutting chain and guide bar. Fill this oil reservoir with new SAE #30 oil, being sure to keep the oil level in the reservoir above the intake tube of the oil pump. When the reservoir is filled and cap replaced, push the oil pump plunger a couple of times until pressure is felt, or until you see oil appearing on the guide bar opposite the oil fitting in the main strut. In extremely cold weather, or when cutting wood which contains a lot of pitch, sap or resin, use a 50-50 mixture of kerosene and oil in the oil reservoir. This will provide good lubrication as well as keeping the guide bar groove and chain comparatively clean.

SAFETY AND FIRE PRECAUTIONS

Your Chainsaw is well-built for maximum safety and efficiency, but carelessness in operation can cause accidents. Read the following suggestions carefully, and remember them as you work with your saw.

1. Do not start the engine in a closed room. Have ample ventilation at all times.
2. Do not touch the chain when the engine is running even at a slow speed.
3. Keep engine adjusted to an idle speed which stops the chain completely.
4. Do not move the chain from one location to another without first stopping the engine.
5. Be sure that the spike bumper (abutment strut) is flush against the sawing log to keep the engine unit from being pulled against the log.
6. Do not operate your chain saw when it needs repair.
7. Do not allow the saw to run while on a cement floor.
8. Do not run saw when it is dull or improperly filed.
9. After refueling, move the engine a few feet away from the fueling site.
10. Keep chain saw clean of dust and inflammables, and check to see that spark plug and electrical connections are tight.


Note! Never Carry the Chain Saw from Place to Place with the Engine Running.

BREAK-IN PERIOD

In order to obtain maximum efficiency and service from your chain saw, it is necessary that the engine be operated during a break-in period of approximately five (5) hours. Never operate the engine without load or allow it to become overheated. Proper breaking in of key parts will have much to do with

the life of your engine. Be sure to check often for loose nuts and screws and make all necessary adjustments. Periodic inspection and service by your authorized Clinton Service Dealer will result in long life and good performance of your Chainsaw.

CHAIN SAW CONTROLS



Major controls on your chain saw are conveniently grouped around the hand grip assembly for finger tip action. You will find your saw easy to manage once you associate the following controls with their locations on the saw. (See Figure 3.)

THE RECOIL STARTER—Located on the left side of the unit. A slight pull will engage the starter with the engine and a spring disengages it when the tension is relieved. **CAUTION:** The starter cable when pulled out, should not be released abruptly and allowed to snap back into its socket. Release slowly to permit complete re-winding.

THE CHAIN OILER—Manually operated, plunger type oil pump, located in the lower portion of the fuel tank just above the hand grip. This system forces oil to the guide bar and chain for positive lubrication.

FUEL SHUT-OFF VALVE—On the bottom of the fuel tank at the lower right. To open, turn counter-clockwise until a slight tension is noticed.

THE THROTTLE CONTROL — Trigger-type, located on the handle grip. The engine speed, or throttle opening, is increased by squeezing the trigger upward into the handle.

THE HIGH SPEED MIXTURE ADJUSTMENT SCREW—Located on the left side of the carburetor. The adjustment is used to obtain proper fuel and air mixture, make the engine run smoothly and achieve maximum power.

THE IDLE FUEL MIXTURE ADJUSTMENT SCREW — This device is found on the left side of carburetor. It is used to obtain smooth and proper idling speed.

THE CHOKE LEVER — Located on the left side of the carburetor just above the adjustment screws.

THE FUEL PUMP — Located in lower section of carburetor maintains proper fuel supply to the carburetor.

THE IGNITION SWITCH — Toggle-type, located directly under fuel tank.

STARTING PROCEDURE

ADJUSTMENT INSTRUCTIONS

To properly adjust carburetor for best performance the engine must be thoroughly warm.

INITIAL ADJUSTMENTS

To start a new engine: First, carefully close by turning clockwise, both Idle and Main Adjustment Screws (Ref. 7 & 19)—located either below air intake opening or at left side of carburetor. Now open Main Adjustment Screw (Ref. 19) counterclockwise approximately one and one-quarter turns ($1\frac{1}{4}$). Open Idle Adjustment Screw (Ref. 7) three-quarters ($\frac{3}{4}$) turn. Back Idle Speed Regulator Screw off its contact with Throttle Stop Lever then turn it inward about one (1) full turn so as to slightly open Throttle Shutter (Ref. 11).

Open fuel shut off valve, choke carburetor, put ignition switch to "ON" position, squeeze throttle trigger and give firm quick pull on starting cord. When engine fires, decrease the choke slightly and ease off the

throttle trigger. Do not race engine, gradually decrease the choke to full open position as engine warms. Then make several test cuts and if necessary, to keep engine from stalling, slightly increase opening of the Main Adjustment Screw (Ref. 19).

FINAL ADJUSTMENTS

Now close throttle and readjust Idle Speed Regulating Screw so engine idle speed is at approximately 1800 to 2200 RPM and without chain turning or throttle trigger being depressed. Then, slowly readjust Idle Adjustment Screw (Ref. 7) to obtain smooth and even engine performance, after which enrichen the mixture slightly above this setting to provide sufficient fuel for quick acceleration. Finally, with saw functioning under a cutting load, slowly readjust Main Adjustment Screw (Ref. 19) to obtain even cutting speed. This setting will vary between one (1) to one and one-half (1½) turns open.

1. Fuel Inlet
2. Fuel Pump Body
3. Fuel Pump Diaphragm
- 3A Fuel Inlet Check Valve
- 3B Fuel Outlet Check Valve
4. Fuel Pump Gasket
5. Diaphragm Cover Gasket
6. Diaphragm Chamber
7. Idle Adjustment Screw
8. Impulse Channel
9. Idle Fuel Adjustment Orifice
- 10A Primary Idle Discharge Port
- 10B Secondary Idle Discharge Port
11. Throttle Shutter
12. Main Fuel Adjustment Orifice
13. Body
14. Venturi
15. Main Fuel Discharge Port
16. Choke Shutter
17. Fuel Inlet Supply Channel
18. Inlet Needle & Seat
19. Main Adjustment Screw
20. Inlet Tension Spring
21. Inlet Control Lever
22. Fulcrum Pin
23. Atmospheric Vent Hole
24. Diaphragm Cover
25. Diaphragm
26. Strainer Gasket
27. Fuel Inlet Screen
28. Strainer Cover Retaining Screw
29. Strainer Cover




FIG. 4

THE CUTTING OF SMALL LIMBS IS CALLED PRUNING.

Pruning Before Felling: Cut from bottom of limb—larger limbs should be undercut, with the final cut made from the top several inches farther out from the trunk.

Pruning After Felling: Always keep the saw blade moving away from the operator.



BUCKING



BUCKING CUT — Small Logs

Try bucking a few stove wood lengths, just to get the feel of your saw.

1. Select a suitable log approximately 12 to 18 inches in diameter.
2. Start your saw according to instructions.
3. Place one hand on the handle grip for complete control of the engine. Use the other hand on the tubular handle to support the unit.
4. Chain should be allowed to feed itself with a minimum amount of pressure on the unit by the operator to achieve best cutting results.
5. As the cut is completed, release the throttle which disengages the clutch.
6. Continue this bucking practice until you are well acquainted with the saw.

BUCKING CUT — Large Logs

To cut a log up to the capacity of the guide bar, start at the top of the log.

1. Raise the power unit and lower the cutting mechanism to begin your cut on the side of the log that faces away from you.

2. Notice that sawing action holds the saw against the log. (See Figure No. 5).
3. After tilting the unit to the maximum angle (about 35°) for the initial cut, pull the chain saw toward you.
4. Repeat this rocking motion until the cut is completed.
5. CAUTION: As the cut nears completion you must be careful to keep the sawing unit from entering the ground. It is sometime possible to roll the log forward and complete the cut from the opposite side, but often this cannot be done, and extreme care is necessary.
6. Release the throttle as you complete the cut, and this action disengages the clutch.

OPERATOR MAKING FINAL CUT (FELLING) PREPARATORY TO FELLING THE TREE.



FELLING CUT

Direction of fall is controlled by the notch.

NOTCHING AND FELLING

For this type of operation rotate the guide bar in a horizontal position against the tree. DO NOT allow spectators within six feet of the chain when it is running.

1. Remember that the undercut notch guides the fall of the tree and should be made with care. By holding your saw at the desired angle any type of notch can be made, but plan carefully. (See Figure No. 6).
2. As you start your felling cut remember to LEAVE HOLDING WOOD (See Figure No. 6) or the tree might spin out of control.
3. Think before you cut!

CHAIN MAINTENANCE AND FILING INSTRUCTIONS




FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 7

1. Place chain in chain filing vise or straight edge vise if possible.
2. Place file holder assembly over rounded cutting tooth. (See Fig. 9) The left hand cutting tooth should be sharpened from the right side and the right hand tooth from the left hand side. Line up filing angle marks on holder with guide bar. Hold file level or 90° to the guide bar.
3. Two or three firm strokes (with pressure applied on the forward stroke) should give a keen edge to the tooth.
4. All teeth must have the same filing angles, the same length, and riders the same height.
5. The center cutters, located between the curved cutting teeth, should be filed with a flat file (See Fig. 10) after all the curved cutting teeth have been filed.
6. Using a flat file the center cutters should be filed on leading edge at 35° angle or at the same angle as cutting teeth. Hold file 90° to the guide bar. Take care that the top of the center cutters are even with the top of curved cutting teeth or .005 below curved cutting teeth. Make sure that they are never above the curved cutting teeth. When finished the center cutters should all be the same length and height.
7. The final step is to file the riders down. This is done with the use of a depth gauge (See Fig. 11). Care should be taken that all riders have the same height and that the leading edge is rounded off after filing. Set riders on direct drive chain saws at .025. Set riders on reduction drive models at .035. See picture.

NOTE: In soft wood, the saw chain depth riders on direct drive may be set at .035 on reduction drive at .045 for faster cutting.






FIG. 8

BAR MAINTENANCE



BAR MAINTENANCE IS IMPORTANT ALSO.

THREE MAJOR FORMS OF BAR WEAR

1	2	3
UNEVEN RAIL WEAR  <p>Causes cut to bend or "run" ... chain to bind in cut.</p>	UNEVEN INSIDE GROOVE WEAR  <p>Causes friction and heat binding and general inefficiency.</p>	WORN RAILS  <p>Shallow groove allows drive links to ride on bottom caus- ing chatter.</p>

JOINTING BAR RAILS



Jointing is the process of making the two rails level and square with each other so as to provide proper bearing surfaces for the bottoms of the tie straps and cutters.

Jointing should be done by your dealer whose shop is equipped to render this service. You can make temporary repair by using the flat file A401906 to even the rails.

CLOSING BAR GROOVES




1. Place a piece of steel (about 6" long and approximately .004" thicker than the drive links) in the groove and lay bar on an anvil with the thin rail up.


2. Use a 3 lb. hammer and close thin rail snugly down on the piece of steel.

3. After each section is closed, drive "piece of steel" forward its entire length and repeat the operation until the entire bar is completed.

BAR MAINTENANCE DUTIES DESCRIBED ABOVE ARE WITHIN THE REACH OF EVERY OWNER. ADDITIONAL DUTIES SHOULD BE HANDLED BY A CLINTON AUTHORIZED SERVICE MAN.



A402554
GREASE GUN
WITH TIP



TIP ASSEMBLY
ONLY



Lubricate Roller Tip frequently. A good grade of light-weight grease is recommended.

SERVICE TIPS

FUEL SYSTEM

The fuel system in your Chainsaw is composed of fuel lines and orifices. It utilizes an automatic fuel pump which puts the proper mixture into action throughout the system. Fuel system defects can cause serious trouble throughout your Chainsaw. At the first sign of trouble of this kind, consult your dealer.

OIL PUMP OPERATION

Since proper lubrication of chain and guide bar is so important, be sure to notice any failure in this system. If oil fails to flow to the guide bar and chain when the oil pump plunger is pushed, or if there is no pressure on the plunger, the pump is not functioning. See your authorized Clinton Service Station Dealer.

GAS CAP AND GASKET

The plastic filler cap like most gas caps has an air-hole in it. This is because the fuel tank must take in air when a vacuum exists in the tank.

MAGNETO ASSEMBLY AND IGNITION SYSTEM (Flywheel Type)

Remember the magneto should be inspected after every 100 hours of operation. If the engine refuses to start or is hard to start, check the gas supply, carburetion system and spark plug. (If the latter is badly burnt, replace.) If the engine still does not start see your authorized Clinton Service Dealer for magneto inspection and repair.

CLEANING VALVE PORTS

Exhaust

The only servicing required for the valve ports is an occasional cleaning to remove carbon deposits.

1. Remove muffler assembly from Chainsaw engine which will expose the exhaust valve ports.
2. Clean with suitable instrument capable of scraping and removing carbon deposits within these ports.
3. The engine should be turned over by hand until the piston moves below the port openings, which will allow greater access for the cleaning of these ports.
4. Care should be taken not to damage or score top of piston when cleaning.

BOW SAW

1. Remove straight guide bar and chain.
2. Mount the Bow Saw blade on the guide bar studs.
3. Place the chain tension plate over the mounting studs and secure with the two replacement nuts in the Parts Bag.
4. For easy installation of chain
 - a. Loosen the tension adjustment.

- b. Place the chain over the drive sprocket and continue to seat it along the blade groove.
- c. Adjust the chain to proper tension by using the adjustment nut.
- d. Start the engine and use the chain oiler freely while the chain is in motion.

HELPERS HANDLE


For specialized sawing operations which require the use of the long guide bar, the Clinton Chainsaw can be fitted with a Helpers Handle for two-man use.

This assembly is in two parts. A mounting stud on the handle-and-guard half slips through the slotted hole in the rounded end of the guide bar. Note that the lugs on either side of the mounting stud engage the slot to position the handle securely. The cover half is then placed over the stud and secured with a washer and wing nut. **Note:** You may have to knock out a tapered plug in the guide bar to install the helpers handle.


MAINTENANCE

By making the following practices a habit you can help keep your saw in good running order and avoid repairs that neglect might make necessary.

1. Remove sawdust and dirt daily so that a thorough inspection can be made.
2. Tighten any loose nuts or screws.
3. Check fuel and oil lines for leaks, especially at connection points.
4. Check air filter and brush off dirt.
5. Do not use compressed air to remove dust or dirt from the OUTSIDE of the carburetor, since particles may be blown into the mechanism if you do.
6. Check muffler and exhaust ports periodically, when the loss of power is apparent. If ports are dirty, clean them.
7. As often as necessary remove the cutting chain from the guide bar and allow it to soak overnight in a pan of kerosene to remove the sap and resin deposits and to provide lubrication for all parts of the chain.
8. If you notice symptoms of trouble but cannot find the cause, check with your authorized Clinton Service Dealer, and be sure your saw is in good running order.



BASIC PARTS BREAKDOWN



D-65-1000 PARTS LIST

Ref. No.	Description	Current No.	IBM No.	Qty.	Ref. No.	Description	Current No.	IBM No.	Qty.
1	Bearing - Ball, Main	233	20-109	1	60	Line Ass'y - Oil	403408	158-306-5	1
2	Bearing Ass'y - Needle	403550	20-197-5	1	61	Line Ass'y - Oil	403423	158-309	1
3	Bearing - Needle (clutch)	402408	20-153	1	62	Line - Air Cleaner	403546	158-313	1
4	Bearing - Roller	403854	20-198-99	1	63	Line - Fuel	403421	158-308	1
5	Block - Cylinder	401832	22-666-5	1	64	Line - Impulse	401528	158-249	1
6	Body - Oil Pump	402880	220-114	1	65	Line - Oil	402419	158-274	1
7	Brace - Strut	402424	26-459	1	66	Linkage - Throttle	401692	159-112	1
8	Bracket - Induction	403849	26-545	1	67	Muffler Ass'y	403885	170-126-5	1
9	Breaker Ass'y	P5735M	135-6-5	1	68	Nut - Reed Plate	403536	183-141	1
10	Bumper Ass'y - Spike	400742	26-417-5	1	69	Nut - Hex. #8-32 (Term.)	P5740	183-21	1
11	Button - Rubber	402441	220-102-99	1	70	Nut - Hex. 7/16 x 20 (Flywheel)	838	183-158	1
12	Cam - Magneto	402967	157-31	1	71	Nut - Plate Chain Tension	403624	183-195	2
13	Cap Ass'y - Fuel	403685	45-197	1	72	Nut - Hex. Terminal	P5740	P183-21	1
14	Cap Ass'y - Oil	400569	45-93-5	1	73	Nut - Acorn	400937	183-175	1
15	Carburetor	403893	39-730-99	1	74	Nut - Stud to Main Casting	402550	183-190	1
16	Clamp - Button to Oil Pump Body	402439	81-125	1	75	Nut - Brace to Brg. Plate	132	183-33	1
17	Clamp - Handle	201	81-87	5	76	Nut - Jam	185	183-131	1
18	Clamp - Wire	402530	263-274	1	77	Nut & L'Washer Ass'y	3255A	183-29-5	2
19	Clip - Core	P5734	81-20	1	78	Nut - Stud Cap	400708	183-171	1
20	Clutch Ass'y	402645	44-71-5	1	79	Pawl - Starter	700915	157-239	2
21	Connector - Oil Pump	402891	69-225	1	80	Pickup with Screen - Oil	402121	25-28	1
22	Core & Breaker Box Ass'y Inc. Ref. No. 23	P5732	P135-37-5	1	81	Pickup with Screen - Fuel	401765	25-26	1
23	Coil Ass'y	P5770	P135-13-5	1	82	Pin - Roll	400863	203-137	1
24	Condenser	P5736	P135-31-5	1	83	Pin - Roll	162	203-107	1
25	Cover - Air Cleaner	401699	45-257	1	84	Pin - Wrist	402131	203-150	1
26	Cover - Dirt	402389	45-279	1	85	Piston	403086	204-66	1
27	Cover - Breaker Box	P5743	45-15	1	86	Plate Ass'y - Chain Ten.	400986	215-368-5	1
28	Cover - Spark Plug	401679	45-256	1	87	Plate Ass'y Stator - Inc. Ref. Nos. 9, 22, 23, 24, 27, 34, 40, 72, 123, 124, 134, 154, 165	P5731D	P268-6-5	1
29	Cover - Spike Bumper	400716	45-20	1	88	Plate - Identification	402222	137-387	1
30	Crankshaft	403272	46-767	1	89	Plate Ass'y - Reed	403793	215-444-5	1
31	Cup Ass'y (Recoil Spring) Decal Kit	P401835	263-251-5	1	90	Plate Ass'y - Retaining	681	215-332-5	1
32	Deflector - Air	402727	259-499	1	91	Plate - Base Pawl	700913	215-437	1
33	Elbow - Check Valve	402414	69-206	1	92	Plate - Bearing	403426	215-417	1
34	Felt Cam Wiper	P5742	94-189	1	93	Plate - Reed	403791	215-444	1
35	Filter Ass'y - Air	403934	2-128-5	1	94	Pulley - Starter	P401869	P219-131-5	1
36	Fitting - Bayonet	91170	69-123	1	95	Retainer - Screen	P402457	P232-113	1
37	Fitting - Oil Pump Check Valve	403422	293-132	1	96	Ring - Lock - Wrist Pin	663	232-119*	2
38	Flywheel Ass'y	402801	83-62-5	1	97	Ring - Piston Compression	400615	233-45	3
39	Friction & Steel Band Ass'y	402639	44-73-5	1	98	Ring - Piston Lock	400616	148-31	3
40	Gasket - Dust Cover	P5744	P94-241	1	99	Ring - Retainer (Bearing)	195	232-83	2
41	Gasket - Bearing Plate	700743	94-421	1	100	Ring - Retainer (Crank.)	700893	232-73	1
42	Gasket - Carburetor to Ind. Bracket	401092	94-242	1	101	Ring - Retainer (Str.)	P401947	P232-109	1
43	Gasket - Ind. Bracket to Reed Plate	403792	94-438	1	102	Rivet - Name Plate	402204	244-75	4
44	Gasket - Muffler to Block	700038	94-394	1	103	Rod & Cap Ass'y Inc. Ref. No. 117	401770	245-69-5	1
45	Gasket - Reed Plate to Blk.	401629	94-360	1	104	Roller	401803	44-46	8
46	Gasket - Spark Plug	3115	94-92-99	1	105	Rope Starter	P700943	P246-6	1
47	Gasket - Spark Plug Cover Gasket Kit	401987	94-362	1	106	Screen - Starter	P402458	P257-81	1
48	Guide Rope	403797	149-370	1	107	Screw - Condenser	P5741	258-299	1
49	Handle - Frame	P401834	111-13	1	108	Screw - Reed Plate	403537	258-516	1
50	Handle - Starter	402537	121-141	1	109	Screw - R.H.S.T. 8-32 x 3/8 (Deflector)	698	258-550	2
51	Handle & L. Mtg. Casting	P700949	P121-182-5	1	110	Screw & Nylock Ass'y 1/4-20 x 1 1/2 (Blower Housing to Strut)	401103	258-643	1
52	Handle & Tank Sdl. Casting	401687	905-15	1	111	Screw - F.H. #4-40 x 3/8 (Oil Pump)	402446	258-720	6
53	Hose - Fuel	403076	905-14	1	112	Screw - #12-24 x 1 Pan Head (Starter)	701013	258-843	4
54	Housing Ass'y - Blower	401497	158-243	1	113	Screw - H.H. 1/4-20 x 1 1/2 (Handle)	850	258-569	5
55	Housing - Starter	401677	259-488-5	1					
56	Hub	P402459	124-119	1					
57	Key - Flywheel	401830	44-48	1					
58	Key - Woodruff	10339	148-4	1					
59	Lead - Wire	184	148-24	1					
		P402965	P307-206-5	1					

Ref. No.	Description	Current No.	IBM No.	Qty.	Ref. No.	Description	Current No.	IBM No.	Qty.
114	Screw & Nylock Ass'y (Induction Bracket)	400177	258-586-5	6	136	Screw - Spike Cover to Spike Bumper	403151	258-741	2
115	Screw & L'Washer Ass'y (Tank Strap)	400189	258-592	2	137	Seal - Oil (Cylinder Block)	402407	94-301-99	1
116	Screw - #10-24 x 1/2 (Pull Guide)	701016	258-845	2	138	Seal - Oil (Bearing Plate)	257-1	94-257	1
117	Screw - Cap to Rod	400585	258-615	2	139	Shorting Ass'y - Ignition	403638	266-41-5	1
118	Screw - Clamp to Carb.	402126	258-710	2	140	Spacer (Starter)	700914	304-524	2
119	Screw - 1/4-20 x 7/8 (Carb. to Ind. Bracket)	365	258-520	2	141	Spacer - Clutch Cover	400540	304-373	1
120	Screw - Handle to Ind. Brkt.	401708	258-678-5	4	142	Spark Plug	K403923	K267-66-5	1
121	Screw & Nylock Ass'y Bearing Plate to Block	400179	258-588-5	4	143	Spring - Starter Pawl	401865	263-171	2
122	Screw - Brg. Plate to Block	401941	258-692-5	2	144	Spring - Oil Pump	402443	263-269	1
123	Screw - Magneto to Bearing Plate	5682A	258-108-5	2	145	Spring - Breaker Box Cvr.	P5745	P263-10	1
124	Screw & Oil Cap Ass'y	P402493	P258-723-5	1	146	Sprocket - Clutch Cup & Brg.	403405	106-239-5	1
125	Screw & Nylock Ass'y Pawl Plate to Flywheel	701028	258-851-5	2	147	Starter Ass'y	402454	265-160-5	1
126	Screw & Nylock Ass'y Blower Hsg. to Brg. Plate	401708	258-678-5	3	148	Stop - Reed	403544	293-97	1
127	Screw - H.H. 5/16-18 x 7/8 (Main Cast. to Block)	403478	258-750	4	149	Strap - Tank Retainer	401700	26-446	1
128	Screw & Nylock Ass'y Tank Saddle to L. Handle	401704	258-677-5	2	150	Strut - Main	403206	26-477	1
129	Screw & Nylock Ass'y Tank Saddle to L. Handle	401733	258-681-5	1	151	Stud - Guide Bar	403189	24-70	2
130	Screw - S.H.C. 1/4-20 x 1 1/2 (Blower Hsg. to Brg. Plate to Saddle)	403071	258-737	1	152	Stud - Muffler to Block	5659	24-11	2
131	Screw - H.H. 5/16-18 x 1 1/4 - (Main Cast. to Sdl.)	403479	258-751	2	153	Tank Ass'y - Fuel	403417	277-323-5	1
132	Screw & Nylock Ass'y Tank Sdl. to Main Casting	671	258-549-5	1	154	Terminal - Jamtite	P5738	P307-230	1
133	Screw - Switch Cover to Saddle Casting	401732	258-680	2	155	Trigger - Throttle	401691	157-296	1
134	Screw & L'Washer Ass'y Breaker	P5737	258-297	1	156	Valve - Fuel Shutoff	401878	293-122	1
135	Screw - Spike Bumper to Main Casting	400709	258-622	2	157	Valve - Reed	403543	293-96	1
					158	Washer - Internal Lock	114	304-3	2
					159	Washer - Brg. Plate to Bk.	657	304-351	4
					160	Washer - Lock (Flywheel)	400874	304-375	1
					161	Washer - Shorting Switch	400323	304-368	1
					162	Washer - Chain Guide	402388	304-430	1
					163	Washer - Lock (Starter)	701012	304-532	4
					164	Washer - Lock (Handle)	403150	304-451	5
					165	Washer - Terminal	P5739	304-290	1
					166	Washer - 2 Plate Chain Ten.			
						2 Spike Bumper to M. Cast.	507	304-337	4
					167	Washer - Lock, Bump. Cvr.	403950	304-451	2
					168	Washer - #10 Lock (Str.)	P192	P304-318	2
					169	Washer - Plain (Str.)	P400624	P304-377	2
					170	Washer - Retaining (Str.)	P401946	P304-412	1
					171	Washer - Wave (Str.)	P401945	P304-411	1
					172	Washer - Lead (Str. Rope)			
						Not Illust.	P700964	P304-525	1
					173	Wire - Shorting	403396	307-265-5	1

D-65-1000 MODEL VARIATIONS

Below is the list of Model Variations on the D-65-1000 Chainsaw as the number appears on the name plate. The parts listed are in addition or are in place of their respective parts. Refer to the Basic Parts List for parts not listed on this page.

D-65-1000: No Variation. Use Basic Parts List.

D-65-1100: Note 1, 2, 3.

D-65-1101: Note 9, 11.

D-65-1102: Note 1, 2, 9, 10.

D-65-1103: Note 4.

D-65-1104: Note 1, 2, 5.

D-65-1105: Note 6.

D-65-1106: Note 1, 2, 7.

D-65-1107: Note 8.

Note 1: Refer to Transmission Parts Breakdown for parts on 2.05:1 ratio transmission.

Note 2: Use 403699 (121-156-5) Handle Assembly, 403415 (81-138) Clamp Joint, 850 (258-569) Screw (2), 657 (304-351) Washer (2), 400584 (183-167) Nut (3).

Note 3: Use 403801 (149-374) Decal Kit.

Note 4: Use 640 (58-167) Decal, 402970 (58-248) Decal.

Note 5: Use 640 (58-167) Decal, 403023 (58-255) Decal.

Note 6: Use 700 (58-170) Decal, 402971 (58-249) Decal.

Note 7: Use 700 (58-170) Decal, 403459 (58-270) Decal.

Note 8: Use 401638 (58-210) Decal, 402936 (58-242) Decal.

Note 9: Use 402878 (277-302-5) Tank, 401361 (45-249) Cap Assembly - Oil, 401365 (94-291) Gasket (2), 402001 (45-270) Cap Assembly - Fuel, 401425 (258-665) Screw (2), 401367 (41-126) Retaining Fuel and Oil Cap Chain (2), 401366 (94-292) Gasket (2), 401684 (26-445) Strap - Tank, 402882 (69-224) Fitting Oil Pump Valve, 402885 (158-290-5) Oil Line.


Note 10: Use 402946 (58-245) Decal, 403700 (58-277) Decal.

Note 11: Use 403802 (149-375) Decal Kit.

TRANSMISSION

LUBRICATION INSTRUCTIONS:

1. Remove Drain Plug (Front of Cover).
2. Remove Filler Plug (Top of Cover).
— Use #90 Oil —
3. Fill Transmission to Oil Level — Oil Level has been reached when oil spills from Drain Plug.
4. Replace Drain and Filler Plug.
— Check Oil Level frequently —



Ref. No.	Description	Part No.	Qty.	Ref. No.	Description	Part No.	Qty.
1	Band Ass'y - Clutch	402639	1	30	Ring - Retaining, Ball Bearing	195	2
2	Bearing - Ball	196	1	31	Rollers - Clutch (Set of 8)	401803	1
3	Bearing - Needle - Reduction	402343	1	32	Screw - Fil. Hd., 1/4"-20 x 3/4" (Cover to Hsg.)	402691	11
4	Bearing - Needle Red. Hsg. Cover	403433	2	33	Screw - S. H. F. H., 5/16"-18-3A x 7/8" (Housing to Block - 4; Housing to Handle - 2)	403478	6
5	Bearing - Needle - Drive Gear			34	Screw - R. H. S. T., #8-32 x 3/8" Dust Shield	698	1
6	Front and Rear Clutch Assembly	402332	2	35	Screw - F. H., #8-32 x 5/8" Clutch Cover	400798	4
7	Connector - Oil Line	403435	1	36	Screw - Soc. Hd. 1/4-20 x 3/4	403393	1
8	Countershaft Ass'y - Color: Yellow	402688	1	37	Screw Blower Hsg. to Brg. Plate	401708	1
9	Countershaft	403429	1	38	Screw & Nylock - H. H. 3/8"-24 x 3/4" Spike Bumper to Strut	401403	1
10	Cover - Clutch	403326	1	39	Seal - Oil, Reduction Housing	402341	1
11	Cover - Dirt	402338	1	40	Seal - Oil, Drive Gear	402333	1
12	Cover & Housing Ass'y	403391	1	41	Shield - Dust	402339	1
13	Cup Ass'y - Clutch	403689	1	42	Spacer - Sprocket	403338	1
14	Crankshaft	402335	1	43	Spike Bumper	402742	1
15	Gasket - Cover to Reduction Hsg.	403339	1	44	Sprocket - (7-tooth)	400221	1
16	Gasket - Housing to Block	402345	1	45	Studs - Guide Bar	402535	2
17	Gear Ass'y - Drive - Color: Yellow	403689	1	46	Washer - Flat, 12/32" x 13/32" x 1/16	507	5
18	Gear - Idler - Color: Yellow	402696	1	47	Washer - Chain Guide	402817	2
19	Gear - Low-Speed - Color: Yellow	403325	1	48	Washer - Thrust, Drive Gear	402334	1
20	Hub Ass'y	402691	1	49	Washer - Thrust, Idler Gear	402328	2
21	Key - Woodruff	403182	1	50	Washer - #8, Clutch Cover	110	4
22	Key - 5/32 Sp.	184	2	51	Washer - Flat	402	1
23	Line Ass'y - Oil, Used on G5-1000	403390	1	52	Washer - Slinger	402323	1
24	Line Ass'y - Oil, Used on 55-1000	403043	1	53	Washer - Lock	403392	1
25	Nut - Grip, 3/8"-24	402550	2	54	Washer - Thrust	402899	1
26	Nut - Hex., 7/16"-20 x 3/8"	400642	1				
27	Nut - Std. 3/8"-24, Guide Bar End of Studs	402521	2				
28	Plate Ass'y - Chain Tension	402324	1				
29	Plug Ass'y - Filler	402346	1				
	Plug - Drain	402351	1				

CHAIN AND GUIDE BAR USAGE CHART

Sprocket Number	D55 Super		D65 Super		R55 Super		R65 Super	
	403407—.404" 7 tooth		403405—½" 7 tooth		400221—½" 7 Tooth		400221—½" 7 Tooth	
	Chain—.058 .404" Pitch	Guide Bar	Chain—.058 ½" Pitch	Guide Bar	Chain—.058 ½" Pitch	Guide Bar	Chain—.058 ½" Pitch	Guide Bar
14" Stellite	H403977	A401231	H403563	A401231	H403563	A401231	H403563	A401231
16" Stellite	H403235	A400855	H403560	A400855	H403560	A400855	H403560	A400855
20" Stellite	H403237	A400854	H403561	A400854	H402187	A400854	H402187	A400854
26" Stellite	XXXXX	XXXXX	H403562	A400870	H402188	A400870	H402188	A400870
30" Stellite	XXXXX	XXXXX	H402189	A401217	XXXXX	XXXXX	H402189	A401217
36" Stellite	XXXXX	XXXXX	XXXXX	XXXXX	XXXXX	XXXXX	H402190	A401218
42" Stellite	XXXXX	XXXXX	XXXXX	XXXXX	XXXXX	XXXXX	H402191	A401230
16" Roller	H403236	A402221	H403557	A402221	H403557	A402221	H403557	A402221
20" Roller	H403238	A401990	H403558	A401990	H403569	A401990	H403569	A401990
26" Roller	XXXXX	XXXXX	H403559	A401991	H403573	A401991	H403573	A401991
30" Roller	XXXXX	XXXXX	H403611	A402551	XXXXX	XXXXX	H403611	A402551
36" Roller	XXXXX	XXXXX	XXXXX	XXXXX	XXXXX	XXXXX	H403612	A402552
			Chain .063 ½" Pitch	Bow Blade	Chain .063 ½" Pitch	Bow Blade	Chain .063 ½" Pitch	Bow Blade
16" Bow Direct Drive	XXXXX	XXXXX	H403973	A403896	XXXXX	XXXXX	XXXXX	XXXXX
18" Bow Gear Drive	XXXXX	XXXXX	XXXXX	XXXXX	H403972	A403897	H403972	A403897

CLINTON CHAINSAW WARRANTY REGISTRATION

CLINTON ENGINES CORPORATION

Maquoketa, Iowa

Clinton, Michigan

You have purchased a Clinton-built Chainsaw, world famous for quality and performance. This Chainsaw is manufactured by Clinton Engines Corporation, builder of the most complete line of Air-Cooled Engines in the world. The Clinton Engines Corporation "Arrowhead" trademark is your guarantee of top performance and long service life. This Chainsaw carries the following warranty.

WARRANTY

This Chainsaw Unit is warranted for 45 days from the date of purchase. The Clinton Engines Corporation will replace at no charge to the original purchaser (end user), any part or parts found to be defective in material and/or workmanship when inspected by an Authorized Clinton Service Outlet or Clinton Engines Corporation. (Normal maintenance on the cutting chain, guide bar, sprocket, and clutch is the responsibility of the owner and/or user. These parts are warranted for defective parts and/or workmanship for a period of 45 days from date of purchase. No part replacement labor allowance.)

All transportation charges on warranty material submitted for replacement is to be paid by the purchaser.

Warranty repairs are to be made by an Authorized Clinton Service Outlet only. There is no other warranty expressed or implied. Clinton Engines Corporation shall in no event be liable for consequential damages.

Clinton Engines Corporation appreciates any opportunity to be of service to you.

HOW TO SECURE SERVICE

Mr. Salesman or Mr. Dealer: Please fill out this warranty form to insure that your customer will receive warranty service if needed.

Mr. Customer: Please retain this warranty form along with your Chainsaw Operation and Maintenance Manual. If warranty service is required, present this completed warranty form to your Authorized Clinton Service Center along with the Chainsaw.

CAUTION: Please read the Operation and Maintenance instructions prior to starting the Chainsaw.

Owner's Name	City	State
Street Address or R. F. D. No.	County	
Chainsaw Model No. (Copy numbers from name plate)	Chainsaw Serial No.	
Date Purchased	Purchased From	
City	County	State

WARRANTY PROCEDURE

If warranty is required:

1. Do not attempt to disassemble or repair Chainsaw or have repairs made other than by an Authorized Clinton Servicing Account.
2. Show the Authorized Clinton Service Account this warranty registration form.
3. Fill out warranty claim completely with Service Account and sign.
4. If a Clinton Service Account is in doubt whether the repairs necessary are warranty, he is within his rights to charge for the repair and fill out a warranty claim for refund which is submitted to his source of supply and is then subject to the source of supply or factory inspection, review, and decision.