




CLINTON ENGINES

SECTION III, DIV. N
 Issued June, 1958
 Revised August, 1965

ELECTRIC STARTER

Starter Ass'y No. 264-63 (6345)



Ref. No.	Part Number	Description	1st. Type	2nd. Type	New Type
1	1-63	ADAPTER - Lead Plug -----	1	1	1
2	4-3-500	ARMATURE ASS'Y -----	1	1	1
3	20-19	BEARING - Flange (Lower) -----	1	1	1
4	264-3	BRUSH - Armature -----	2	2	2
5	44-8-500	CLUTCH ASS'Y -----	1		
	44-84-500	CLUTCH ASS'Y -----		1	
	44-8-500	CLUTCH ASS'Y -----			1
6	307-51	CORD - Extension -----	1	1	1
7	45-70-500	COVER ASS'Y - Electric Starter -----	1	1	1
8	264-5	CUP -----	1		
9	106-113	GEAR - Clutch -----	1		
	106-15	GEAR - Clutch -----	1	1	
	106-110	GEAR - Clutch -----			1
10	70-10	GROMMET -----	4	4	4
11	124-77	HOUSING - Upper -----	1	1	1
12	124-76-500	HOUSING - Lower -----	1	1	1
13	135-213-500	LAMINATION ASS'Y -----	1	1	1
14	183-26	NUT - Hex, #8 -----	5	5	5
15	183-25-500	NUT & L'WASHER -----	4	4	4
16	203-104	PIN - Centering -----	1	1	1
17	215-165-500	PLATE - Brush Mounting -----	1	1	1
18	216-56	PLUG - Starter -----	1	1	1
19	232-76	RING - Retaining -----	1	1	1
20	258-191	SCREW - 10-32x1/2 -----	4	4	4
21	258-111	SCREW - 8-32x4 1/4, R.H.M. -----	2	2	2
22	258-113	SCREW - 8-32x5/16, P.H.S.T. (Lead Cord Adapter to Cover) -----	2	2	2
23	258-114	SCREW - 8-32x5/16, P.H.M. (Ground) -----	1	1	1
24	304-304	SPACER - Brush Mounting Plate -----	2	2	2
25	304-66	SPACER - Mounting -----	4	4	4
26	263-180	SPRING - Armature, Brush -----	2	2	2
27	307-235	TERMINAL -----	2	2	2
28	304-286	WASHER - Fiber -----	1	1	1
29	304-12	WASHER - Lock, Ext. Tooth #8 -----	2	2	2


Check Price List For Complete Unit and Individual Parts Availability.

Printed in U. S. A.



ELECTRIC STARTER

Starter Ass'y No. 264-62 (6344)



Ref. No.	Part Number	Description	1st. Type	2nd. Type	New Type
1	4-4-500	ARMATURE ASSEMBLY -----	1	1	1
2	20-19	BEARING - Flange (Lower) -----	1	1	1
3	264-56	BRUSH - Armature -----	2	2	2
4	44-8-500	CLUTCH ASSEMBLY -----	1		
	44-84-500	CLUTCH ASSEMBLY -----		1	
	44-8-500	CLUTCH ASSEMBLY -----			1
5	45-70-500	COVER ASSEMBLY - Electric Starter -----	1	1	1
6	264-5	CUP -----			
7	106-113	GEAR - Clutch -----	1		
	106-15	GEAR - Clutch -----		1	
	106-110	GEAR - Clutch -----			1
8	70-10	GROMMET -----	4	4	4
9	124-32	HOUSING - Upper -----	1	1	1
10	124-76-500	HOUSING - Lower -----	1	1	1
11	264-57	INSULATOR - Connector Plate -----	1	1	1
12	135-214-500	LAMINATION ASSEMBLY -----	1	1	1
13	304-12	LOCKWASHER - Ext. Tooth (#8) -----	4	4	4
14	183-26	NUT - Hex. #8 -----	4	4	4
15	183-25-500	NUT & L'WASHER -----	4	4	4
16	203-104	PIN - Centering -----	1	1	1
17	215-310	PLATE - Brush Mounting -----	1	1	1
18	215-180-500	PLATE - Connector -----	1	1	1
19	232-76	RING - Retaining -----	1	1	1
20	258-191	SCREW - 10-32x1/2 -----	4	4	4
21	258-112	SCREW - 8-32x5 -----	2	2	2
22	258-113	SCREW - 8-32x5/16, P. H. S. T. (Adapter to Cover) -----	2	2	2
23	258-114	SCREW - 8-32x5/16, P. H. M. (Ground) -----	2	2	2
24	304-41	SPACER - Brush Mounting Plate -----	2	2	2
25	304-305	SPACER - Connector Plate (Cardboard) -----	1	1	1
26	304-660	SPACER - Mounting -----	4	4	4
27	263-180	SPRING - Armature Brush -----	2	2	2
28	266-9-500	SWITCH ASSEMBLY - Push Button -----	1	1	1
29	304-286	WASHER - Fiber -----	1	1	1
30	307-133	WIRE - Battery Lead -----	1	1	1

Check Price List For Complete Unit and Individual Parts Availability.